





LEGEND

-  Casper Tank
-  Casper Booster Station
-  CWRWS Tank
-  CWRWS Booster Station

Zone	Overflow El.	Service El.
Zone 1	5335	5100 – 5220
Zone 2	5500	5220 – 5380
Zone 2A	5416	5220 – 5320
Zone 2B	5448	5220 – 5340
Zone 3	5650	5380 – 5550
Pioneer	5667	5220 - 5570
Zone 4	5808	5550 – 5700

5800

5700

5600


5500

5400

5300

5200

5100



**FIGURE 5-2
HYDRAULIC GRADE LINE
SCHEMATIC**